The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.



923-0300 (3-80) DADB PARTS CATALOG

INTRODUCTION

This catalog applies to the standard Alternators listed below. Parts are arranged in groups of related items. Each illustrated part is identified by a reference number corresponding to the same reference number in the parts list for that group. Parts illustrations are typical. Using the *Model* and *Spec No.* from the nameplate, select the *Parts Key No.* 1, 2, etc., in the last column) that applies to your set *Model* and *Spec No.* This *Parts Key No.* represents parts that differ between models. Unless otherwise mentioned in the description, parts are interchangeable between models. Right and left sides are determined by *facing* the blower end (front) of the set.

GENERATOR SET DATA TABLE

		PARTS				
MODEL AND SPEC	WATTS	VOLTS	HERTZ	PHASE	KEY NO.	
4.0 DADB-3P/*	4000	120/249	60	1	1	
°4.0 DADB-3E/*	4000	120/240	60	1	2	

The Specification Letter advances (A to B, B to C, etc.) with manufacturing changes.

PARTS CATALOG INDEX DADB


FICHE	LOC	AT.	IO!	N					GROUP
A1				•					GENERATOR SET DATA TABLE
A1				•	-	•		-	STANDARD PARTS SECTION
A6		•		-	•	-	_	_	CARRYING HANDLE
A7		•	-	•					CONTROL (AC-OUTPUT)
A6			-	-	-		-	•	CONTROL (ENGINE)
A 5		ų	-	-		_	-		END BELL
A3,	.A4		_		_				GENERATOR SET
A8								-	OPTIONAL PARTS SECTION
A9			_						DOLLY
A9		•							RECEPTACLE PLUG

STANDARD PARTS SECTION



^{* -} These Generator Sets are electric starting.

GENERATOR SET





GENERATOR SET


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	100-1714	1	*Engine, Replacement -	45	CONTROL.	ASSEMBL	.Y - AC
			Petter ACI MKV551		(See Separa	ite Group f	or Components)
2	403-1587	2	Channel, Mounting		300-2042	1	Key 1
3	815-0500	2	Screw. Cap - Hex Head		300-2 020	1	Key 2 ¹
			W/ET (5/16-18 x 3/4")	46	815-0498	4	Screw. Cap - Tapping Hex
4	8 70-0348	2	Nut. Hex W/ET (5/16-18)				Head W/Cone Washer
5	862-0003	4	Nut. Hex (3/8-16)				(#8-32 x 3 '8")
6	8 00-0051	4	Screw, Cap - Hex Head	47	416-0734	1	Cable, Battery (14") - Key 2
_	400 4000		(3/8-16 x 1-1/4")	48	416-0735	1	Cable Battery (38") - Key 2
7	403-1609	1	Bracket, Generator Mounting	50	402-0290 402-0410	4	Bushing Steeve
8 9	856-0910	1	Washer, Lock - EIT (3/8)	51 52	402-0410	4 4	Cup, Darnpenar Retaining
a	815-0391	,	Screw, Tapping - Slotted Hex Head (#10-32 x 1/2")	53	526-0198	8	Snubber, Rubber Washer, Flat (5/8" ID x
10	153-0514	1	Clamp, Choke Cable	55	320-0190	0	1-1/2" OD x 1/16")
11	815-0351	1	Screw, Cap - Hex Head	54	526-0014	4	Washer, Flat (29/64" ID x
	010-0001	,	Brass (#8-32 x 3/8")	J-1	320 3014	™.	1-1/2" OD × 1/8")
12	152-0230	1	Swivel, Cable Holding	55	850-0055	4	Washer, Lock - Spring (7/16)
13	516-0059	•	Cotter, Hairpin	56	862-0004	4	Nut. Hex (7/16-14)
14	821-0018	j	Screw. Cap - HWH	57	816-0206	4	Screw, Cap - Hex Head
•		-	(1/4-20 x 5/8")		•		(7/16-14 x 3-1/2")
15	152-0233	1	Bracket, Throttle Cable	58	526-0286	4	Washer, First /1-1/8" ID x
			Mounting				1-3/4" OD y 3/16")
16	402-0284	4	Dampener, Vibration	61	416-0338	1	Frame, Battery Hold-down -
17	403-1635	1	Frame, Carrying				Key 2
21	870-0212	1	Nut. HWH (1/4-20)	62	526-0113	3	Washer, Flat (11/32" ID x
22	WASHER, I	LOCK - SPI	RING (3/8)				1" OD x 3/32")
	850-0050	6	Key 1	63	800-0192	2	Screw, Cap - Hex Head
	850-0050	12	Key 2				(1/4-20 x 8-1/2") - Key 2
24	332-2325	1	Clamp, Throttle Cable	64	850-0040	2	Washer, Lock - Spring (1/4) -
25		1	Control, Engine (See Separate	***			Key 2
			Group for Components)	70	98-4063	1	Label, Service Instructions
26			IEAD (3/8-16 x 1-1/2")	71	856-0003	1	Washer, Lock - EIT (#10)
	800-0052	2	Key 1	72 73	337-0097 332-2178	1	Strap, Ground Lug, Single - Terminal
20	800-0052 850-0045	8	Key 2 Washer, Lock - Spring (5/16)	74	815-0378	2	Screw, Tapping - Hex Head
28 29	800-0045	1 1	Screw, Cap - Hex Head	/4	810-0376	~	W/ET (#14 x 1/2")
25	600~0030	'	(5/16-18 x 1-1/4")	80		1	Plate, Model Identification
30	231-0227	1	Adapter (includes Dowel	81	98-4023	i	Labei, Receptacle Panel
00	EG. OZZ.	•	Pins)	82	98-3575	1	Label, Caution
31	B15-0494	4	Screw, Cap - Hex Head	83	508-0051	1	Grommet, Rubber (2" Hote)
•	5.0 5.0.	•	W/IT (3/8-16 x 7/8")			,	
32	201-2910	1	Rotor (Includes Bearing)	90	403-1641	1	Bracket, Lifting
33	520-0916	1	Stud, Rotor Through	91	104-1155	1	Shaft, Stub - Engine to
34	870-0271	1	Nut, Internal Wrenching				Generator
35	220-3108	1	Stator	92	801-0517	4	Screw, Cap - Hex Head
36	211-0328	1	Beit Assembly, End (See				(5/16-24 x 1-3/4")
			Separate Group for	94	231-0247	1	Adapter, Engine to Generator
			Components)	100	191-1304	1	&Starter, Complete (Lucas
37	234-0637	1	Cover, Brush Block				#M35J 25219A/H)
38	815-0395	4	Screw, Tapping - HWH	_	_		
			(#6 x 3/8")		For compone	nt parts, c	ontact your nearest Petter dealer
39	800 -01 8 9	4	Screw, Cap - Hex Head				ontact your nearest Lucas dealer
	070 5555	_	(1/4-20 x 8")				notive Equipment Division
40	870-0232	4	Nut - Hex W/ET (1/4-20)	!	5500 New Kin	g Street, 1	Froy, Michigan 48098.
43	301-5359	1	Wrapper, Receptacle Panel				
44	821-0009	4	Screw, Cap - HWH (1/4-20 x 3/8")				
			(17-20 x 310)				

er.



er 5500 New King Street, Troy, Michigan 48098.


· END BELL



REF		QTY.	PART
NO.	NO.	USED	DESCRIPTION
	211-0328	1	Bell Assembly, Complete
1	211-0324	. 1	Bell Only, End
2	510-0047	1	Bearing, Rotor
3	815-0359	2	Screw, Tapping - HWH
			(#10-32 x 7/8")
4	332-1876	1	Clamp, Wire Retaining
5	815-0518	1	Screw, Tapping - HWH
_			(#6-32 x 5/8")
6	51 6- 0196	4	Pin, Locking - End Bell
7	312-0194	1	Bracket, Capacitor
_			Mounting
8	356-0056	1	Capacitor
9	212-1271	1	Block, Collector Ring
			Brush (Includes Parts
			Marked *)
10	214-0096	2	*Brush, Collector Ring
11	212-1232	2	*Spring, Brush
12	LEAD (#16 W	(ire)	•
	33 6 -5252	1	18" Long
	336-5251	1	5" Long
	336-5249	1	17" Long
	336-5248	1	4" Long
	336-5250	1	3" Long
13	232-0596	1	Clip, Generator Bearing
			Stop




CARRYING HANDLE



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	403-1477	4	Grip, Handle
2	403-1588	2	Tube, Handle
3	814-0185	6	Screw, Machine - Flat Head Slotted (5/16-18 x 2-1/4")
4	870-0348	6	Nut, Hex - W/ET (5/16-18)


ENGINE CONTROL



REF. NO.	PART NO.	GTY. USED	PART DESCRIPTION
1	152-0234	1	Bracket, Engine Control
2	308-0345	1	Switch, Start - Key 2
3	336-5475	2	Lead (14"-#16 Wire) - Key 2
4	153-0527	1	Control, Engine Fuel On/Off
5	FLUG, NYLON		, - , 3 ,
	517-0131	1	3/8" Hole
	517-0133	1	7/16" Hole - Key 1



CONTROL (AC OUTPUT)



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
		SSEMBL	Y, COMPLETE	11	822-2050	1	Screw, Machine - Pan Head
	300-2042	1	Key 1				W/ET (#8-32 x 3/4")
_	300-2020	1	Key 2	12	323-1107	1	Receptacle, Twistlock - 30 Amp,
1	WASHER, LC	OCK - EI	• •				120 Volt (Three Wire,
	853-000 5	7	Key 1				NEMA #L5-30R)
	853-00 05	3	Key 2	13	323-1108	1	Receptacle, Twistlock - 20 Amp,
2	301-5782	1	Panel, Control - Blank				240 Volt (Three Wire,
3	323-1104	7	Receptacle, Duplex				NEMA #L6-20R)
		_	(15 Amp, 125 Voit)	14	308-047 9	1	Switch, Toggle
4	822-2030	5	Screw, Machine - Pan Head W/ET (#6-32 x 3/8")	15	812-0197	1	Screw, Machine - Round Head (#8-32 x 2-1/4") - Key 2
5	BREAKER, C	IRCUIT		16	321-0233	1	Fuse, 8 Ampere - Key 2
	320-0540	2	15 Ampere	17	321-0175	1	Holder, Fuse - Key 2
	320-0541	2	20 Ampere	18	357-0030	1	Rectifier, Silicon - Key 2
	320-0543	. 1	30 Ampere	19	336-4458	1	Lead - Key 2
6	854-0023	5	Washer, Lock - IT (7/16")	20	336-6210	1	Lead - Key 2
7	332-2139	1	Terminal, Tab (4 Place)	21	336-4792	1	Lead - Key 2
8	PLUG, DOT 6	NOTTUE	(1/2" HOLE)	23	526-0003	2	Washer, Flat (11/64" ID x
	517-0133	4	Key 1				3/8" OD x 1/32") - Key 2
	517-0133	3	Key 2	24	304-0217	1	Resistor, Fixed
9	305-0548	1	Rectifier, Bridge				(1-Ohm, 10 Watt) - Key 2
10	NUT, HEX (#8	8-32)		25	304-0292	1	Insulator, Resistor - Key 2
	860-0008	1	Key 1		· - 		
	860-0008	2	Key 2				



OPTIONAL PARTS SECTION

This section contains illustrated parts listings of optional accessories and factory installed options for the generator sets. Options may not be applicable to all models; for field conversions additional parts are usually required. Optional parts listed in this section are in addition or in place of those shown in the standard parts section.



RECEPTACLE PLUG (OPTIONAL)












REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	323-0988	As Req	'Plug. Receptacle - NEMA #5-15P-(15 Amp. 120 Volt)
5	323-0216	As Req.	*Plug. Receptacle - NEMA #6-15P-(15 Amp. 240 Volt)
3	323-0862	As Req	*Plug. Twistlock - NEMA #L-30P-(30 Amp. 120 Volt)
4	323-0863	As Req.	*Plug, Twistlock - NEMA #L6-20P-(20 Amp, 240 Volt)
5	323-0952	As Req.	*Plug. Twistlock - NEMA #L14-30P-(30 Amp. 240 Volt)
6	323-1143	As Req.	*Plug. Twistlock - NEMA *L6-30P-(30 Amp, 240 Volt)

* - Select plug according to recepta to recipitation illustrated.

DOLLY KIT - OPTIONAL



REF. NO.	PART NO.	QTY. USED	DESCRIPTION
	410-0739	1	Dolly, Package, Complete
1	410-0738	1	Axie, Dolly
2	870-0329	2	Nut, Hex - Self Locking (5/16-18)
3	814-0186	2	Screw, Machine - Slotted Flat Head (5/16-18 x 2-1/2")
4	526-0081	8	Washer, Flat (1-1/64" ID x 1-5/8" OD x 1/8")
5	410-0236	2	Wheel + Tire, Complete
6	516-0198	4	Clip, Hitch Pin
7	410-0147	2	Handle, Dolly
	410-0742	2	Channel, Handle Mounting
9	800-0052	2	Screw, Cap - Hex Head (3/8-16 x 1-1/2")
10	406-0062	2	Nut, Handle
11	800-0032	4	Screw, Cap - Hex Head (5/16-18 x 1-3/4")
12	862-0015	4	Nut, Hex (5/16-18)
13	850-0045	4	Washer, Lock - Spring (5/16)
14	403-0205	2	Grip, Handle
15	410-0238	2	Lock, Handle
16	854-0020	2	Washer, Lock - IT (3/8)

